


# Zebra RS5100 20-SLOT SCANNER CHARGER Lade-/Dockingstation

<b>Artikelnummer</b>	998710018
<b>Gewicht</b>	1kg
<b>Länge</b>	1mm
<b>Breite</b>	1mm
<b>Höhe</b>	1mm



## Produktbeschreibung

Zebra RS5100 20-SLOT SCANNER CHARGER Lade-/Dockingstation

Produktbeschreibung:

20-Slot Ring Scanner Charging ShareCradle - RS5100

- Charges up to twenty RS5100 units simultaneously

- Requires RS5100 unit with Standard Charge Connector

Trigger - Can be racked in a standard 19" rack system via the mounting accessory (BRKT-SCRD-SMRK-01)

- Requires Power Supply (PWR-BGA12V108W0WW),

DC Cable (CBL-DC-381A1-01) and country specific

three-wire grounded (C13) AC Line Cord,

all sold separately

Technische Details:

Allgemein

Gerätetyp

Ladestation für Barcode-Scanner - extern

Verschiedenes

Besonderheiten

LED-Anzeiger

Informationen zur Kompatibilität

Entwickelt für

Zebra RS5100

## Produkteigenschaften

<b>Produkttyp</b>	Ladestation für Barcode-Scanner
<b>Farbkategorie</b>	Schwarz
<b>Anzahl Anschlüsse</b>	20
<b>Stromversorgungsgerät - Formfaktor</b>	Extern

## Weitere Bilder

